

STEP ONE: FIND THE PERCENT SLOPE WHICH BEST DESCRIBES YOUR PROPERTY.

Hold this line parallel to the ground

Punch hole here

Thread string through the hole and tie a knot.

1. Punch a hole through this diagram at the designated spot. Mount diagram on cardboard if needed.
2. Thread a 12" piece of string through the hole and tie a knot in the end of the string on the backside of the diagram.
3. Tie a 1" or larger washer to weight the other end of the string.
4. Hold the designated line parallel to the ground, sighting up slope along the edge of the diagram.
5. The weighted string will indicate the percent of slope steepness. For convenience, steepness of slope in degrees is listed in parenthesis.

